

ReziKleen X1

RESIN CLEANER & MOLD BUILD UP REMOVER

ReziKleen X1 is a concentrated cleaning solution designed to dissolve and emulsify resin, waxes, dirt, and other residues. It is suitable for use with epoxy, polyester, silicone, polysulfide, and many urethane resin systems. ReziKleen X1 is economical and can be used as-is for tough jobs or diluted with 1 or 2 parts water to 1 part of the ReziKleen X1 to create a multipurpose cleaning solution. We suggest using the most dilute solution that provides the necessary cleaning performance.

ReziKleen X1 is free-rinsing and contains corrosion protection additives. However, metal surfaces that are prone to corrosion should be exposed to the solution for only limited periods and should be rinsed and dried immediately after cleaning.

APPLICATION INSTRUCTIONS

To use, dilute the ReziKleen X1 to the desired concentration. The solution may be applied using a spray bottle, with a sponge, or by placing the item to be cleaned into the solution container. For best results allow the solution to soak into the surface for 30 seconds to 1 minute and then lightly scrub surface with a stiff bristle brush, a scouring pad, or other means of mechanically loosening the surface contaminants.

Repeat as necessary to remove all contaminants, then wash the surface clean with distilled or deionized water. Dry the surface completely when done rinsing.

PACKAGING AVAILABLE

This product is available in a wide range of package sizes including quart, gallon, and 5-gallon pails.

STORAGE GUIDELINES

Store the ReziKleen X1 and solution made from it should be kept in clean, dry environment in their tightly closed original containers. Store at 50°F – 104°F (10°C - 40°C). Tightly re-seal containers after use to prevent evaporation. If the recommended storage conditions are observed the products will have a minimum shelf-life of 24 months from the date of shipment.

Please note: that the ReziKleen X1 may freeze at around 32°F (0°C). If this occurs, allow the container to warm to room temperature until completely re-liquefied and shake to re-mix prior to use.

HANDLING PRECAUTIONS

Product Datasheet



Mandatory and recommended industrial hygiene procedures should be followed whenever these products are being handled and processed. For additional information please consult the corresponding material safety data sheets.

ReziKleen X1 - CAUTION! In keeping with good industrial. Keep away from eyes, skin, and clothing. Wash skin and clothing thoroughly after handling. Avoid breathing vapor or mist and use with adequate ventilation. Keep containers closed when not in use. Do NOT take internally.

FIRST AID

In case of contact: **Skin** – Immediately wash skin thoroughly with mild soap and water. Remove contaminated clothing and wash before reuse. Destroy contaminated shoes and other articles made of leather. **Eyes** – Immediately flush eyes with plenty of water for 15 minutes and get prompt medical attention. **Inhalation** - Remove person to fresh air. Administer oxygen or artificial respiration if necessary. Call a physician. **Ingestion** - Do not induce vomiting. Dilute with plenty of water and contact physician immediately. Never give anything by mouth to an unconscious person.

DISCLAIMER - IMPORTANT: The following supersedes Buyer's documents. **SELLER / MANUFACTURER MAKES NO REPRESENTATION OR WARRANTY, EXPRESS OR IMPLIED, INCLUDING OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** No statements herein are to be construed as inducements to infringe any relevant patent. Under no circumstances shall Seller / Manufacturer be liable for incidental, consequential or indirect damages for alleged negligence, breach of warranty, strict liability, tort or contract arising in connection with the product(s). Buyer's sole remedy and Seller's sole liability for any claims shall be Buyer's purchase price. Data and results presented are based on controlled or laboratory work and must be confirmed by Buyer by testing for its intended conditions of use. The product(s) has not been tested for, and is therefore not recommended for, uses for which prolonged contact with mucous membranes, abraded skin, or blood is intended; or for uses for which implantation within the human body is intended

Specialty Polymers & Services, Inc. (SP&S)

27822 Fremont Court

Valencia, CA 91355

www.spolymers.com

Tel: 661-294-1790

Fax: 661-294-0640

info@spolymers.com