



Distributed by Specialty Polymers & Services  
661-294-1790 or [info@spolymers.com](mailto:info@spolymers.com)

## PROVISIONAL DATA SHEET

# TDT 178-57 ACCELERATOR FOR REN:C:O-THANE<sup>®</sup> POLYUREA SYSTEMS

**DESCRIPTION:** TDT 178-57 is a concentrated catalyst for accelerating the cure of polyurea systems. TDT 178-57 is a liquid which is easily blended into the hardener components of REN:C:O-THANE Polyurea.

**APPLICATIONS:** For use only with RP 6442, RP 6443 and RP 6444 and their various custom-colored products. Not recommended for use with REN:C:O-THANE polyurethane systems.

**MIXING INSTRUCTIONS:** TDT 178-57 accelerator should be added to the hardener components (amine) of REN:C:O-THANE polyureas. Only a small amount of accelerator is required to increase the speed of the curing process. TDT 178-57 accelerator will reduce the working life of the system you are using. This reduction in working life is dependent upon added accelerator concentration, shop temperature, material temperature, and quantity of the polyurea being mixed.

The effect of the TDT 178-57 accelerator varies between the REN:C:O-THANE systems as well. Begin your evaluation by adding no more than 0.2% TDT 178-57 to the hardener component you wish to try. (That is: 0.2 grams TDT 178-57 to 100 grams of REN:C:O-THANE hardener.) The quantity of 0.2 grams equals two or four eyedropper drops. Mix thoroughly before adding the required REN:C:OTHANE resin amount (see container label or data sheet for the system you are using).

Cure a test part alongside an unaccelerated sample to gage the effect the addition has made. You should look for an increase in hardness build-up and a reduction in demold time.

Another good tactic is to add a small amount of TDT 178-57 accelerator and increase the starting temperature of the resin, hardener, and/or mold about 10 to 20°F over ambient temperature.

Accelerator additions of greater than 1.5% are likely to yield erratic results and very short working times. You should carefully evaluate your cured part against your performance requirements to determine if the accelerator addition produces acceptable parts in your application.

**COMPARISON OF “GEL” AND “HARDNESS BUILD-UP” OF RenSHAPE SOLUTIONS’ POLYURETHANE MATERIALS, USING ACCELERATORS**

Product	Percent (%) Accelerator	T-CAM Gel (4 oz.)	SHORE HARDNESS AT 77°F (IN HOURS)					
			1	2	4	8	16	24
RP 6442	0	36 mins			34 A	60 A	71 A	80 A
RP 6442	0.1	14 mins		20 A	54 A	71 A	79 A	85 A
RP 6442	0.5	14 mins	20 A	25 A	71 A	80 A	83 A	87 A
RP 6443	0	23 mins		65 A	76 A	88 A	92 A	95 A
RP 6443	0.1	16 mins	46 A	77 A	81 A	89 A	93 A	94 A
RP 6443	0.5	8.6 mins	75 A	84 A	89 A	94 A	95 A	95 A
RP 6444	0	28 mins		20 D	33 D	46 D	45 D	58 D
RP 6444	0.1	16 mins	15 D	26 D	41 D	51 D	49 D	58 D
RP 6444	0.5	7 mins	35 D	45 D	54 D	54 D	53 D	60 D

GEL TIMES = 4 fl.oz. (150g)

HARDNESS = 60 g.in aluminum dish (1/4" thick sample) TEST  
TEMPERATURE = 74°F (60% R.H.)

**STORAGE/HANDLING INFORMATION:**

**TDT 178-57 Accelerator**

Store at 70-90°F. This product is moisture-sensitive and packaged under a blanket of dry nitrogen. Maintain factory seal. After use, reblanket with dry nitrogen and tightly reseal.

In accord with good industrial practice, handle with due care. Avoid dusty conditions, use adequate ventilation. Avoid breathing dust. Avoid contact with eyes, skin, and clothing. Wash thoroughly after handling.

**SHELF LIFE:** Provided materials are stored under the recommended storage conditions in their original containers, they will remain in useable condition for at least one year from date of shipping.

**PACKAGING:** This product is available in the following package size(s):

- TDT 178-57 available in quart units weighing 1.5 pounds.

Please call Customer Service (800-367-8793) for price and availability.

**SAFETY/HANDLING PRECAUTIONS:** Do not use or handle this product until the Material Safety Data Sheet has been read and understood.

**TDT 178-57 Accelerator**

**WARNING!** Causes skin and eye irritation. May cause allergic skin reaction. Avoid contact with eyes, skin, and clothing.

Avoid prolonged or repeated contact with skin.

Wash thoroughly after handling.

**FIRST AID:** In case of contact with:

**Skin:** Immediately wash with soap and water. Remove contaminated clothing and launder before reuse. Destroy contaminated shoes.

**Eyes:** Immediately flush with water for at least 15 minutes. Call a physician.

**Ingestion:** If conscious, give plenty of water to drink. Do not induce vomiting. Call a physician.

**Inhalation:** Remove to fresh air. Administer oxygen or artificial respiration if necessary. Call a physician.

**Other:** Referral to physician is recommended if there is any question about the seriousness of any injury.

**IMPORTANT:** The following supersedes Buyer' s documents. SELLER MAKES NO REPRESENTATION OR WARRANTY, EXPRESS OR IMPLIED, INCLUDING WARRANTIES AND CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. No statements herein are to be construed as inducements to infringe any relevant patent. Under no circumstances shall Seller be liable for incidental, consequential, or indirect damages for alleged negligence, breach of warranty, strict liability, tort, or contract arising in connection with the product(s). Buyer' s sole remedy and Seller' s sole liability for any claims shall be Buyer' s purchase price. Data and results are based on controlled or lab work and must be confirmed by Buyer by testing for its intended conditions of use. The product(s) has not been tested for, and is therefore not recommended for, uses for which prolonged contact with mucous membranes, abraded skin, or blood is intended; or for uses for which implantation within the human body is intended.

Vantico A&T US, Inc.  
RenShane Solutions  
4917 Dawn Avenue  
East Lansing, MI 48823 USA

Tel 517 351 5900  
800 375 1363  
[www.tooling.vantico.com](http://www.tooling.vantico.com)

Customer Service Hotline: 800 367 8793  
Technical Inquiries: 800 759 7165  
Product Literature: 800 955 5509